


Description of the electronics board



- 1 – JP2 pins to set the type of visual signaling,
- 2 – the way of putting jumpers on JP2 pins for the respective types of optical signaling.

Types of optical signaling

In order to set the selected type of optical signaling, put the jumpers on the JP1 and JP2 pins accordingly:

- I - two flashes followed by one- second pause,
- II - slow flashing (once per second),
- III - fast flashing (twice per second),
- IV - steady light (regardless of the jumper setting on the JP1 pins),
- V - no light (regardless of the jumper setting on the JP1 pins).